

如何修复显示器上的“无视频”

How to Fix “No Display” on Monitor

注意：以下操作请不要安装硬盘，正常情况会直接进入 BIOS 或者 EIF SHELL.

Note: Please do not install the hard drive for the following operations. Normally, it will directly enter BIOS or EIF SHELL.

1. 连接显示器，启动电源.

1. Connect the monitor and turn on the power.

2. 如果显示器黑屏，主板电源灯不亮，可能是 BIOS 数据异常，需要重置 BIOS 数据。如果重置 BIOS 后依然不亮，需要联系售后人员。

2. If the monitor goes black and the motherboard power light is not on, it may be due to abnormal BIOS data, which needs to be reset. If the BIOS still does not light up after resetting, please contact after-sales service.

3. 如果显示器黑屏，主板指示灯正常:

3. If the display screen is black and the motherboard indicator light is on normally:

A. 按电源键，指示灯会关闭（这种情况主板已经启动了）

A. Press the power button and the indicator light will turn off (in this case, the motherboard has already started)

1. 更换一个显示接口

1. Replace the display interface with a new one

2. 更换一条视频线

2. Replace a video cable

3. 如果依然不行，请尝试更换一台显示器来验证

3. If it still doesn't work, please try replacing another monitor to verify

B. 按电源键，指示灯不会关闭

B. Press the power button, the indicator light will not turn off

1. 重置 BIOS 数据

1. Reset BIOS data

2. 更换一条正常的内存

2. Replace with a workable memory

3. 如果依然不行，需要联系售后人员

3. If it still doesn't work, please contact after-sales service